

BATHTUB RECAULKING

Over time, general wear and tear can degrade the appearance and functionality of your bathtub sealant. Regular maintenance can help prevent leaks and water damage.



1 Remove the old caulk and vacuum the area.



2 Use Goof Off® to remove sticky residue.



3 Use Simple Green® to clean the area.



4 Apply even tape lines to the top and the bottom of tub.



5 Apply a steady bead of caulk and smooth.



6 Wait for caulk to dry thoroughly and remove masking tape.

SUPPLIES TO DO THE JOB



Warner Tool® 5-In-1
Glazier Knife
531430



Goof Off® Pro
Strength Remover
101110 ⚠ See Footnote



DAP Kwik Seal Plus
Kitchen & Bath Caulk
108730 ⚠ See Footnote



Stanley® Classic 99®
Retractable Utility Knife
130152



Half Barrel Smooth
Rod Caulk Gun
201080



Shurtape® Painter's
Masking Tape
128872



PRO TIP

After removing caulk, spray a solution of 50%/50% bleach and water around the open seam to kill any mold or mildew.

⚠ WARNING: California Residents, this product contains chemical(s), which is/are known to the State of California to cause cancer and/or birth defects or other reproductive harm. Find more information by visiting hdsupplysolutions.com to review the specific product details.

© 2008 - 2022. HDS IP Holding, LLC. All Rights Reserved. HD Supply® and the HD Supply logo are trademarks of HDS IP Holding, LLC. For our terms and conditions, visit hdsupplysolutions.com/terms.

22-22431

3 EASY WAYS TO ORDER



MOBILE APP



1.800.431.3000



hdsupplysolutions.com