

# **CARE INSTRUCTIONS USER GUIDE**

## Best Practices For Laundering Fitted Mattress Pads Like Commercial Laundries

#### **PROPER SORTING**

**Color Type:** Separate colored ones to prevent color bleeding.

**Fabric Type:** Sort fitted mattress pad by fabric type to ensure each fabric receives the correct washing treatment.

#### PRE-TREATMENT

Spot-Treat Stains: Apply a stain remover before washing to prevent stains from setting in during the wash cycle.



#### **WASHING CYCLE**

#### **Water Temperature:**

**Mattress pads:** Wash temperature range should be between 99°F/37°C and 109°F/43°C.

**Cycle Time:** A standard wash cycle for fitted mattress pad should last about 30 minutes.

# DETERGENT AND CLEANING SOLUTIONS

**Detergent:** High-quality, industrial-grade detergents are designed for commercial laundries and formulated to handle large loads and tough stains.

Bleach: DO NOT BLEACH.

### **DRYING CYCLE**

Temperature: Dry at low heat settings - 130°F/54°C to ensure thorough drying.

**Drying Time:** A typical drying cycle until dry. Check fitted mattress pad periodically to prevent over-drying and remove them promptly once dry to avoid wrinkles.



#### **DO'S & DON'TS**

- **DO** Use Appropriate Detergents: Choose detergents specifically formulated for commercial use to ensure effective cleaning and fabric care.
- **DO** Regular Maintenance: Regularly maintain and clean laundry equipment to ensure optimal performance and prevent contamination.
- **DON'T** Overload Machines: Overloading washing machines can lead to inadequate cleaning.
- **DON'T** Use Excessive Chemicals: Excessive use of harsh chemicals can damage fibers and reduce their lifespan.

© 2008 - 2025. HDS IP Holding, LLC. All Rights Reserved. HD Supply® and the HD Supply logo are trademarks of HDS IP Holding, LLC. For our terms and conditions, visit hdsupplysolutions.com/terms.

25-24042







